

INSTALLATION OVERVIEW | ENVIROGRID® GEOCELL



INSTALLATION COMPONENTS

4-8 man installation crew

- Infill Material
- Zip Ties or Staples
- EnviroGrid® Panels
- 6oz Non-Woven Geotextile
- Bulldozer or Skid Steer
- Roller



STEP 1: PREPARE

- Prepare sub-base by ensuring that it has proper drainage and grading the area as needed.
- Install geotextile fabric by rolling it out directly on top of the prepared sub-base area.



STEP 2: CONNECT PANELS

- Attach the sides of the panels using zip ties or staples.



STEP 3: EXPAND PANELS

- Expand the panels out across the prepared surface and shake out as needed to fit the installation area.



STEP 4: FILL GEOCELL

- Fill the geocell with the desired infill material by dumping the material onto the system.
- Then, push the infill into the system using an bulldozer or skid steer. Overfill the cells by 1"-2".



STEP 5: COMPACT

- Compact the surface layer of the infill material using a roller. The EnviroGrid® should not be visible underneath the infill material.



DRIVE: READY TO USE

- The EnviroGrid® system is immediately able to be driven on top of once the cells are filled.

