

Repair Kit Instructions

Dear Valued Customer:

Below are instructions for the repair kit you recently requested:

1. Cut old surface edges, clean with utility knife, and prime edges with Polyurethane glue.
2. With gloves, mix 4 lbs. (2 quarts) of polyurethane glue with 1 bucket of pre-mixed colored rubber thoroughly.
3. Trowel in place with putty knife or trowel.
4. To clean and release materials from putty knife or trowel, use mineral spirits or paint thinner.
5. Let cure 48 hours.

If you have any questions or further instructions are needed please call 225-215-7760.

We appreciate your business.

No Fault Surfacing, LLC