



FTSTR / RSTR Ground Mount Delineator Post

Installation Instructions

1) Preparation

Assemble the materials and tools needed.

2) Installation

a) Manually dig a pilot hole the depth of the chosen anchor deep into the ground. Alternative methods include using a post hole digger or an auger.

- Most installers will use pneumatic drivers to drive the PSST into the ground as they would with a sign post anchor.
- If Pneumatic drivers are used skip steps b) & c).

b) Place the post with anchor attached into the pilot hole to the proper depth on the post to the first ring on hinge.

c) Back fill around post and tamper in firmly.

3) Orientation and Pinning

a) Orientate the post so that flat surface on a FTSTR is facing traffic and then insert post and hinge into installed anchor and pin in place with a quick release pin.

b) For the RSTR, simply insert post into installed anchor and pin in place, no orientation is required.

Important Notice to Purchaser

The following is made in lieu of all warranties, expressed or implied, including the implied warranties of merchantability and fitness for purpose: Seller's and manufacturer's only obligation shall be to replace such quantity of the product proved to be defective. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith. Neither manufacturer nor seller shall be liable either in tort or in contract for any loss or damage, direct, incidental, or consequential, arising out of the use of or the inability to use the product.